



Plantronics .Audio™ 655

User Guide

Welcome

Congratulations on purchasing your new Plantronics .Audio™ 655. This User Guide contains instructions for setting up and using the .Audio 655. Please refer to the separate For Your Safety guide for important product safety and charging information prior to installation or use.

Getting Assistance

The Plantronics Technical Assistance Center is ready to assist you. You can find answers to frequently asked questions, ask a question using e-mail, receive service over the Internet, or speak directly with a representative. Call (800) 544-4660 or visit www.plantronics.com/support



Registering Your Product

Visit www.plantronics.com/product registration to register your product online so we can provide you with the best service and technical support.

Contents

Package Contents and Features	1
Using Your Headset	2
Headset Controls	3
Operating Systems Configuration	4
Indicator Light	6
Limited Warranty	7

Package Contents and Features



Using Your Headset

Congratulations, you can now listen to your favorite music or talk with friends and family using your new headset.

Using Your Headset

- 1 Connect headset to a USB port on your computer.**
Your computer and USB hub (if using) should be turned on.

Headset Controls

Adjust volume

Increase: Press +

Decrease: Press -

⚠WARNING Do not use headsets at high volumes for an extended period of time. Doing so can cause hearing loss. Always listen at moderate levels. See www.plantronics.com/healthandsafety for more information on headsets and hearing.

Muting the microphone

Mute: Lift the boom to full stop.

Unmute: Lower the boom.

CAUTION Do not force the boom past its upper or lower limits.

Operating Systems Configuration

Your .Audio 655 headset works with any USB-compliant computer. Below are details on how to set the audio device for the most popular operating systems.

NOTE On-ear controls may not function properly with operating systems earlier than Windows XP.

Windows XP®

- 1** Go to **Start > Control Panel > Sounds and Audio Devices**.
- 2** On the **Audio** tab, select “**Plantronics Audio 655**” as the **Sound Playback** and **Sound Recording** device.
- 3** On the **Voice** tab, select the “**Plantronics Audio 655**” as the **Voice Playback** and **Voice Recording** device.
- 4** On the **Volume** tab, adjust the **Volume Slider** as necessary. Do not select the **Mute** option.
- 5** Select **OK**.

Operating Systems Configuration

Windows Vista

- 1** Go to **Start > Control Panel > Classic View > Sounds**.
- 2** On the **Playback** tab, select the “**Plantronics Audio 655**” as the **Sound Playback** device.
- 3** Select **Properties**, and on the **Levels** tab, adjust the **Volume Slider** as necessary. Do not select the **mute** option. Select **OK**.
- 4** On the **Recording** tab, select the “**Plantronics Audio 655**” headset as the **Sound Recording** device.
- 5** Select **Properties**, and on the **Levels** tab, adjust the **Volume Slider** as necessary. Do not select the **mute** option. Select **OK**.
- 6** Select **OK**.

Mac® OS X

- 1** Go to **System Preferences > Sound**.
- 2** On the **Output** tab, select the “**Plantronics Audio 655**” headset as the **Sound Output** device.
- 3** Adjust the **Output Volume Slider** as necessary. Do not select the **mute** option.
- 4** On the **Input** tab, select the “**Plantronics Audio 655**” headset as the **Sound Input** device.
- 5** Adjust the **Input Volume Slider** as necessary.
- 6** Select **OK**

Indicator Light—Headset

Status	Indicator
Power On/Off	On: Steady blue glow Off: off

Limited Warranty

This warranty covers defects in materials and workmanship of products manufactured, sold or certified by Plantronics which were purchased and used in the United States and Canada.

The warranty lasts for one year from the date of purchase of the products.

This warranty extends to you only if you are the end user with the original purchase receipt.

We will, at our option, repair or replace the products that do not conform to the warranty. We may use functionally equivalent reconditioned/refurbished/remanufactured/pre-owned or new products or parts.

To obtain service in the U.S., contact Plantronics at (800) 544-4660. To obtain service in Canada call (800) 540-8363.

THIS IS PLANTRONICS' COMPLETE WARRANTY FOR THE PRODUCTS.

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state. Please contact your dealer or our service center for the full details of our limited warranty, including items not covered by this limited warranty.



345 Encinal
Santa Cruz, CA 95060
United States
Tel: 800-544-4660
www.plantronics.com

©2009 Plantronics, Inc. All rights reserved. Plantronics, the logo design, .Audio, and Sound Innovation are trademarks or registered trademarks of Plantronics, Inc. Windows XP and Windows Vista are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Mac OS X and iTunes are trademarks of Apple, Inc. registered in the US and other countries. All other trademarks appearing herein are the property of their respective owners.
81182-01 (02/09)