


# Panasonic

Model No. **KX-TG7341E**  
**KX-TG7342E**

## Quick Guide

### Connections


#### Base unit



#### Important:


- If you use a telephone line cord which is not supplied, the unit may not work properly.

#### Charger (KX-TG7342)



## Battery installation/Battery charge

**Charge for about 7 hours.**



### Note:


- **USE ONLY Ni-MH batteries AAA (R03) size.**
- **Do NOT use Alkaline/Manganese/Ni-Cd batteries.**

## Operating tips

### Using the navigator key


The handset navigator key can be used to navigate through menus and to select items shown on the display by pressing [**▲**], [**▼**], [**←**], or [**→**].

**To adjust the receiver or speaker volume,** press [**▲**] to increase the volume, or press [**▼**] to decrease the volume repeatedly while talking.




### Soft keys

The handset features 3 soft keys. By pressing a soft key, you can select the feature shown directly above it on the display.




## Date and time (Handset)

- 1  (middle soft key)
- 2 **[▼]/[▲]**: "Handset Setup" → **OK**
- 3 **[▼]/[▲]**: "Time Settings" → **OK**
- 4 **[▼]/[▲]**: "Set Date & Time" → **OK**
- 5 Enter the current date, month, and year.
- 6 Enter the current hour and minute.
- 7 **OK** → **[⏏]**

## Basic operations

### Making/Answering calls (Handset)



Making calls	Dial the phone number. → <b>[📞]/[📞]</b>
Answering calls	<b>[📞]/[📞]</b>
To hang up	<b>[⏏]</b>
To adjust the receiver/ speaker volume	Press <b>[▲]</b> or <b>[▼]</b> repeatedly while talking.
Making a call using the redial list	<b>[📞]</b> (right soft key) → <b>[▼]/[▲]</b> : Select the desired phone number. → <b>[📞]</b>
Handset ringer volume	<ol style="list-style-type: none"> <li>1  (middle soft key)</li> <li>2 <b>[▼]/[▲]</b>: "Handset Setup" → <b>OK</b></li> <li>3 <b>[▼]/[▲]</b>: "Ringer Setup" → <b>OK</b></li> <li>4 <b>[▼]/[▲]</b>: "Ringer Volume" → <b>OK</b></li> <li>5 <b>[▼]/[▲]</b>: Select the desired volume. → <b>OK</b> → <b>[⏏]</b></li> </ol>

### Making/Answering calls (Base unit)


Making calls	<b>[📞]</b> → Dial the phone number.
Answering calls	<b>[📞]</b>
To hang up	<b>[📞]</b>
To adjust the speaker volume	Press <b>[▲]</b> or <b>[▼]</b> repeatedly while talking.
Redialling the last number dialled	<b>[📞]</b> → <b>[📞]</b>
To adjust the base unit ringer volume	Press <b>[▲]</b> or <b>[▼]</b> repeatedly to select the desired volume. • To turn the ringer off, press and hold <b>[▼]</b> until the unit beeps.

**Basic operations****Phonebook (Handset)**

## Adding entries

- 1  (left soft key) → 
- 2 **[v]/[^]**: "New Entry" → **OK**
- 3 Enter the party's name (16 characters max.). → **OK**
  - You can change the character entry mode by pressing **1/A/2**.
- 4 Enter the party's phone number (24 digits max.). → **OK** 2 times → **[X0]**
  - To enter a name, see the character table in the operating instructions.

## Making calls

- 1  (left soft key)
- 2 **[v]/[^]**: Select the desired entry.
  - You can scroll through the phonebook entry by pressing and holding **[v]** or **[^]**.
- 3 **[~]**

**Answering system (Base unit)**




## Answering on/off

Press **[05]** to turn on/off the answering system.


## Listening to messages

**[▶]**

## Frequently asked questions

Question	Cause/solution
Why is  flashing?	<ul style="list-style-type: none"> <li>• The handset is too far from the base unit. Move closer.</li> <li>• The base unit's AC adaptor is not connected. Check the connections.</li> <li>• You are using the handset or base unit in an area with high electrical interference. Re-position the base unit and use the handset away from sources of interference.</li> <li>• The handset is not registered to the base unit. Register it (page 7).</li> </ul>
What should I do when the handset does not turn on?	<ul style="list-style-type: none"> <li>• Make sure the batteries are installed correctly.</li> <li>• Fully charge the batteries.</li> <li>• Clean the charge contacts and charge again.</li> </ul>
How long is the battery operating time?	<ul style="list-style-type: none"> <li>• When you are using fully-charged Ni-MH batteries (supplied batteries); In continuous use: 17 hours max. Not in use (standby): 150 hours max.</li> <li>• It is normal for batteries not to reach full capacity at the initial charge. Maximum battery performance is reached after a few complete cycles of charge/discharge (use).</li> <li>• Actual battery performance depends on a combination of how often the handset is in use and how often it is not in use (standby).</li> </ul>
Can I keep the handset on the base unit or charger when I am not using it?	<ul style="list-style-type: none"> <li>• Even after the handset is fully charged, the handset can be left on the base unit or charger without any ill effect on the batteries.</li> </ul>
When should I replace the batteries?	<ul style="list-style-type: none"> <li>• If the batteries are fully charged until  is displayed, but  is displayed after a few calls, replace the batteries with new ones.</li> </ul>
What is a PIN?	<ul style="list-style-type: none"> <li>• The PIN is a 4-digit number that must be entered in order to change certain base unit settings. The default PIN is "0000".</li> </ul>
What should I do to display caller information?	<ul style="list-style-type: none"> <li>• You must subscribe to a Caller ID service. Contact your service provider/telephone company for details.</li> <li>• The message "<b>You must first subscribe to Caller ID.</b>" will be displayed until you receive caller information after subscribing to a Caller ID service.</li> </ul>






### Frequently asked questions


Question	Cause/solution
What should I do when noise is heard, sound cuts in and out?	<ul style="list-style-type: none"><li>• You are using the handset or base unit in an area with high electrical interference. Re-position the base unit and use the handset away from sources of interference.</li><li>• Move closer to the base unit.</li><li>• If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.</li></ul>
What should I do when the operating time seems to be shorter even after I fully charged the batteries?	<ul style="list-style-type: none"><li>• Clean the battery ends (+, -) and the charge contacts with a dry cloth, and charge again.</li></ul>
What do I need to do to erase → (Missed call) from the display?	<ul style="list-style-type: none"><li>• There are unviewed missed calls remaining. View them and erase → in the following way.<ol style="list-style-type: none"><li>1  (middle soft key)</li><li>2 [v]/[▲]: "Caller List" → <b>OK</b></li><li>3 Press [v] to search from the most recent call, or press [▲] to search from the oldest call.</li></ol></li></ul>

## Registering a handset to the base unit


The supplied handset and base unit are pre-registered. If for some reason the handset is not registered to the base unit, re-register the handset.

### Handset


- 1  (middle soft key)
- 2 /: "Handset Setup" → **OK**
- 3 /: "Register H.set" → **OK**



### Base unit

Press and hold  for about 5 seconds, until the registration tone sounds.


- The next step must be completed within 90 seconds.



### Handset

Wait until "Enter Base PIN" is displayed. →  
Enter the base unit PIN (default: "0000"). →  
**OK**



- When the handset has been registered successfully,  stops flashing.

### Optional service (Caller ID)

If you subscribe to a Caller ID service,



caller information will be displayed when a call is received, or when viewing missed calls.

### Sales and support information

#### Customer Care Centre

- For customers within the U.K.: 0844 844 3898
- For customers within the Republic of Ireland: 01289 8333
- Visit our website for product information: [www.panasonic.co.uk](http://www.panasonic.co.uk)
- E-mail: [customer.care@panasonic.co.uk](mailto:customer.care@panasonic.co.uk)

#### Direct Sales at Panasonic U.K.

- Order accessory and consumable items for your product with ease and confidence by phoning our Customer Care Centre Monday - Thursday 9:00am - 5:30pm, Friday 9:30am - 5:30pm (Excluding public holidays).
- Or go on line through our Internet Accessory ordering application at [www.panasonic.co.uk](http://www.panasonic.co.uk)
- Most major credit and debit cards accepted.
- All enquiries transactions and distribution facilities are provided directly by Panasonic U.K. Ltd.
- It couldn't be simpler!
- Also available through our Internet is direct shopping for a wide range of finished products, take a browse on our website for further details.

**Customer Care Helpline Tel. No.: U.K. 0844 844 3898 / R.O.I. 01289 8333**



**Notes**

## IMPORTANT

If you have any problems operating this product, please try the following:

① **Reconnect AC adaptor.**



② **Use supplied telephone line cord.**



③ **Use rechargeable Ni-MH batteries.**  
(Alkaline batteries **CANNOT** be used.)



Refer to **Troubleshooting** in Operating Instructions  
and **FAQs** in this Quick Guide.



If you still have any problems, please call  
the Panasonic DECT Helpline

**0844 844 3898 (U.K.)**

**01289 8333 (Rep of Ireland)**

Lost Operating Instructions? Download at [www.panasonic.co.uk](http://www.panasonic.co.uk).