

# **D770 - D770A**

## **QUICK START GUIDE**

**SaGeMCOM**



Dear customer,

You have just acquired a new generation Sagemcom telephone. Thank you for placing your confidence in us. This device has been manufactured with the utmost care.

This product follows a strategy of continuous development. We reserve the right to make changes, modifications and improvements without notice to the products described in this quick start guide.

If you should have difficulties in operating it, we recommend that you consult this quick start guide.

You can also find the complete user guide on the following website **[www.sagemcomdigital.co.uk](http://www.sagemcomdigital.co.uk)**. It includes all the available menus of your device.

To operate the device safely and easily, please read carefully the paragraph “**Recommendations and safety instructions**”, page 4.



The CE label confirms that the product complies with the 1999/5/EC regulations of the European Union Parliament regarding wireless systems and telecommunications.

The declaration of compliance may be looked up on the **[www.sagemcom.com](http://www.sagemcom.com)** website section «Support», or can be obtained from the following address:

**Sagemcom Broadband SAS**  
250, route de l'Empereur  
92848 Rueil-Malmaison Cedex - France

Copyright © Sagemcom Broadband SAS / All rights reserved / Sagemcom is a registered trademark.

# Recommendations and safety instructions



For safety reasons, never put the handset in the base station without the battery inserted or without the lid on the battery compartment as this could cause an electric shock.

To avoid damaging your handset/base, only use certified rechargeable battery NiMH 2.4 V 600 mAh, never use non-rechargeable batteries. Insert the battery in the handset battery compartment.



Only use the power unit supplied and connect it to the electricity mains in accordance with the installation instructions in this user manual and the details on the sticker regarding voltage, electrical current and frequency. As a precaution if there is a risk of danger, the power plug can be pulled out to disconnect the 230 volt power supply. Therefore the sockets should be near the device and easily accessible.



Do not install your DECT telephone in a damp environment, such as a bathroom, washroom, kitchen etc, and not within 1.50 metres of a source of water or outside. This device is designed for use in temperatures of between 5 °C and 40 °C.



Your DECT telephone has a range of approx. 50 metres indoors and up to 300 metres outdoors. The range can be affected by the proximity of metal objects, such as a television and electrical devices. Zones without reception may appear owing to elements in the building. This can cause brief interruptions in the conversation, caused by faulty transmission.



Certain medical equipment and highly-sensitive machines or security systems may be affected by the transmission power of the telephone. In these cases we recommend adhering to the safety information.



In regions greatly affected by electrical storms we recommend that you protect your telephone circuit with a special fixture for excess voltage.



Your D770/A has anti-skid pads that should leave no traces on your furniture and ensure stability. However, given the wide variety of finishes used by furniture manufacturers, traces may appear on surfaces in contact with the parts of your D770/A. Sagemcom Broadband SAS decline all responsibility in any such cases of damage.



Do not attempt to remove screws or open the appliance. It does not contain any user-replaceable parts.



Worn out batteries must be disposed of in line with the recycling regulations in this user manual.



This product is intended to be connected to the public analogue telephone network of any British or Irish network operator. Should you experience any problems, contact your nearest specialist dealer or the Sagemcom Support Team on **0845 0900 316**.

# Discover...

## Your phone

### The pack

Check that you have the following items in your pack:

- ☒ a **D770** or **D770A** base according to model,
- ☒ a rechargeable battery (type NiMH 2.4 V 600 mAh),
- ☒ a telephone connection cord,
- ☒ a mains power supply with connection cord,
- ☒ this quick quick start guide.

If you have purchased a **DUO** or **TRIO** pack, you will also find for each extra handset:

- ☒ a charger,
- ☒ a mains power supply with connection cord,
- ☒ a rechargeable battery (type NiMH 2.4 V 600 mAh).



## The base

- 1 Handset(s) Search / Pairing key.
  - *Long press*: pairing of handsets.
  - *Short press*: paging of handsets.
- 2 Handset location.
- 3 Indicator light.

### Indicator light operation:

<b>Fixed</b>	handset on line.
	- or - answering machine activated *
<b>Blinking</b>	New message(s) on your answering machine *
	- or - Accessing the answering machine menu from the handset/remote querying *.
	- or - Recording an outgoing message *

\* Only for **D770A**



# The handset



1 Loudspeaker

2 Graphic screen

3 Browser

4 Menu access / validation key:  
confirm / acces to the menu  
and/or options

5 "Hang up" key:  
• *Short press*: back to the main  
menu / end a call (*during a call*)  
• *Long press*: switch off / switch  
on the handset

6 Alphanumeric keypad

7 "Hash" key:  
• *Long press* : (de)activate the  
silent mode

8 Mute button : cuts off the  
microphone (*during a call*)

9 Microphone

10 Cancel / Intercom key:  
• back to the previous menu  
• Correct the entry/ Cancel  
• Call an additional handset (from the  
standby screen)

11 "pick up" key

12 key 1  
• *Long press*: access to voicemail  
service (to set voicemail number,  
refer to the section "Changing your  
voice mail number" in the complete  
user guide on the following website  
[www.sagemcomdigital.co.uk](http://www.sagemcomdigital.co.uk)

13 "Star" key"  
*Long press* : (un)lock the keypad

14 Hands-free key: enable / disable  
hands-free mode (*during a call*)

15 R key (flashing, to manage several  
calls)

## Browser

To access the phone menu, press **OK**<sub>MENU</sub>.

When choosing menus, press the up ▲ or the down ▼ the left ◀ the right ▶ of the browser.

In the list of options, press the up ▲ or the down ▼ of the browser.

### From the standby screen:

Access to received call list

### In a menu:

Navigate left (◀)

### From the standby screen:

Access to the Redial list

### In a menu:

Navigate up (▲)

### From the standby screen:

Access phonebook

### In a menu:

Navigate down (▼)

### From the standby screen:

No action

### In a menu:

Navigate right (▶)







# Set-up...

## Connect the base

Before making connections, please see the safety instructions at the start of the booklet.

- 1 Take the telephone connection cord, click it into its socket and connect the other end of the cord to the telephone socket.
- 2 Take the power adapter. Connect the end of the cord to the base and the power adapter to the wall socket.




## Handset set-up




- 1 Take the battery provided in the packaging.
- 2 Insert the connector into its housing complying with the positions of the wires.
- 3 Slide the battery pack into its housing.
- 4 Fit the battery compartment cover to the handset.

## Charging the handset



- 1 Gently lower the handset onto the base charging blade. Contacts within the body of the blade ensure electrical contact with the handset.
- 2 Slide the handset downwards.
- 3 Perform a complete battery charging cycle.


The battery charging icon  moves to inform you that charging is in progress. The icon display stops moving when the batteries are charged.

**To ensure optimum charging, leave the handset on the charger for at least 15 hours when using the phone for the first time. During charging, the battery may heat up. This is quite normal and perfectly safe.**

## The handset screen

In standby mode or during use, your phone screen informs you of your phone's current state through icons, and in particular:

- 1 Status icons:** Indicates your phone's current state.
- 2 Information field:**
  - Standby screen :in the normal state, displays the name of the handset and the current time and date.
  - In the menus: displays the selected menu name, function or setting.
- 3 Action area:** displays the actions associated with the multi-function keys **C** and **OK** in the ongoing menu (refer to section "The multifunction keys", page 13).



### THE ICONS DISPLAYED

icon	Description
	DECT signal
	New missed call(s)
	Answering machine activated ( <b>0770A</b> )
	New message(s) on your answering machine
	New message(s) on your answering voicemail
	Alarm on

icon	Description
	Battery charge condition
	Silent mode activated
	Keypad locked
	Speakerphone enabled
	Phone in conversation mode


# Browsing through the menus

## The multifunction keys

Your telephone has two multifunction keys **C**<sub>INT</sub> and **OK**<sub>MENU</sub> which you can use in several ways:

	From the standby screen	In a menu
<b>OK</b> <sub>MENU</sub>	To access the telephone menu.	To enter a menu, to validate an action in a menu.
<b>C</b> <sub>INT</sub>	To make an Intercom call (call to another handset).	To return to the previous menu. To delete characters. With each press, the character preceding the cursor is deleted.


## Main menu



\* Only for **D770A**

## Example

To browse through menus, use the browser arrows and the two multifunction buttons:

- 1 Press the key **OK**<sub>MENU</sub>. The main menu is displayed on the screen.
- 2 Press the up ▲ or down ▼ or the left ◀ or the right ▶ of the browser to scroll through the menus and access the desired menu.
- 3 Confirm your choice by pressing the key **OK**<sub>MENU</sub>.
- 4 Press the up ▲ or down ▼ to scroll through the menus and access the desired function.
- 5 Confirm your choice by pressing the key **OK**<sub>MENU</sub>.
- 6 Cancel your choice / Exit the displayed menu :
  - either by pressing the key **C**<sub>INT</sub>.
  - or by pressing the red key ; the home screen is displayed.

## To access the date and time setting menu

### ADJUST THE DATE AND TIME

To access the date and time setting menu:

Go to the menu <b>Settings &gt; Date &amp; Time &gt; Set Time/Date</b>	This means that you can access this function by displaying the menu, then scrolling down through the options displayed until you reach the function <b>Set Time/Date</b> .
---	--

To proceed :

- 1 Press the key **OK**<sub>MENU</sub>. The main menu is displayed on the screen.
- 2 Select the menu **Settings** by pressing the up ▲ or down ▼ or the left ◀ or the right ▶ of the browser.  
Confirm your choice by pressing the key **OK**<sub>MENU</sub>.

- 3 Scroll through the menus to the **Date & Time** menu by pressing the up ▲ or down ▼ of the browser.  
Confirm your choice by pressing the key **OK** MENU.
- 4 Scroll through the menus to the **Set Time/Date** menu by pressing the up ▲ or down ▼ of the browser.  
Confirm your choice by pressing the key **OK** MENU.
- 5 Enter the time: using the numeric keypad (hours then minutes). Confirm your entry by pressing the key **OK** MENU.
- 6 Enter the date using the numeric keypad (day, month and year) in the form DD/MM/YYYY. Confirm your entry by pressing the key **OK** MENU.


Refer to the “**Menu tree structure**”, page 18 section to find out about your phone’s functions.


# Making and receiving calls...

## Managing a call


### Making a call

#### METHOD 1



- 1 Dial your contact's number.  
If you make a mistake, press the  key to delete the last character entered.

- 2 Press the green key .

#### METHOD 2

- 1 Press the green key .
- 2 Dial your contact's number.

### Receiving a call

- 1 Press the green key  to take the call.
- 2 At the end of the call, press the red key .


## Options during a call

### Enable/Disable hands-free mode

During a call, press  key. The icon  appears on the handset screen.

When the battery charge icon is at minimum, the hands-free function is not available until the next charging cycle.

### Adjusting the volume


To increase the volume, press  key.

To decrease the volume, press  key.

### Enabling/Disabling the secret mode



During a call, press **MUTE** key. The icon  appears on the handset screen.

## Locating your handset

If you have misplaced your handset, press the  key on the base. The handset rings.

## Using the phonebook

### Create an entry

- 1 Go to the menu **Phonebook**.  
If there are no entries, the message **List Empty** is displayed.
- 2 Select **New Entry** with the  or  key and press **OK**.  
MENU



- 3 Specify the required information by confirming at each step with **OK**<sub>MENU</sub>.

## Listening and Recording (D770A)

### Enabling/disabling the answering machine

- 1 Go to the menu **Answer Machine > Answer On/Off**.
- 2 Select the desired state, **On** or **Off**, press **OK**<sub>MENU</sub>.

### Answering machine announcements


#### Recording a personal outgoing message

- 1 Go to the menu **Answer Machine > Greeting Msg. > Record OGM > Answ & Record (or Answer Only)**.
- 2 Record your message then press **OK**<sub>MENU</sub>.  
The recorded announcement is played.

### Erasing your outgoing message

- 1 Go to the menu **Answer Machine > Greeting Msg. > Play OGM > Answ & Record (or Answer Only)**.
- 2 During the playback of the personal announcement used, press **OK**<sub>MENU</sub>.

### Playing messages

If you have received new messages, icon  appears on the handset screen and Indicator light on the base flashes.

- 1 Go to the menu **Answer Machine > Play messages**.
- 2 You can carry out the following operations:

Key	Action
2	Delete the current message
4	1 press: replay the current message 2 presses: play the previous message
5	Stop playing the messages
6	Play the next message

# Menu tree structure

## Phonebook

- New Entry Option
  - Calling Number
  - Edit Entry
  - View Entry
  - Copy Entry <sup>(1)</sup>
  - Copy All <sup>(1)</sup>
  - Delete Entry
  - Delete All
  - Capacity
  - Edit Call Group
  - Speed Dial

## Audio

- Ring Tone Setup
  - External Calls
  - Internal Calls
  - Volume
  - Silent
- Signal Tones
  - Key Tone
  - Confirm Tone
  - Low Battery
  - Out of Range

## Display

- Handset Name
- Screensaver
- Contrast

## Settings

- Date & Time
  - Time Format
  - Date Format
  - Set Time/Date
- Display
  - Handset Name
  - Screensaver
  - Contrast
- Handset
  - Select Base
  - Language
  - Auto Answer
  - Register HS
  - De-register
  - Reset Handset
- Base
  - Flash Time
  - Dial Mode
  - Call Sharing
  - Change PIN
  - Reset Base
- Mailbox

## Alarm

- Alarm X<sup>(2)</sup>
  - Alarm On/Off
  - Time
  - Melody

## Answer Machine <sup>(3)</sup>

- Play messages
- Delete Old Msgs
- Answer On/Off
- Greeting Msg.
- Record memo
- Settings
  - Answer Mode
  - TAM Language
  - Answer Delay
  - Recording Time
  - Remote Access

*(1): You must have at least two handsets registered on the same base.*

*(2): X from 1 to 5*

*(3): Only for D770A*

# Environment

Environmental protection and sustainable development is an important priority for Sagemcom. Sagemcom has a policy of using environmentally- friendly systems and makes environmental protection an essential part of the life-cycle of its products – from manufacturing, to installation, operation and disposal.

## Packaging



The logo (green point) on the packaging means that a fee is paid to an authorised national organisation to improve packaging recycling and the recycling infrastructure. Follow the local sorting regulations for this type of waste product in order to improve recycling.

## Batteries

If your product contains batteries, they must be disposed of at the designated collection points.

## The product



The crossed out dustbin displayed on the product signifies that it belongs to the electrical and electronic equipment group. The European regulations request you to carry out your own selective recycling collection at:

- the sales outlet when you buy a similar new device.
- the collection points available in your area (recycling centres, sorting points, etc).

This means you participate in the recycling and valorisation of used electric and electronic goods which would otherwise have a negative impact on the environment and health.

# Terms and Conditions for United Kingdom & Ireland only

In order to apply the guarantee, or for technical assistance, you should contact the Sagemcom Helpdesk (**0845 0900 316**) or the retailer you purchased your equipment from.

Please make sure that you use your equipment only for the purpose for which it was designed and under normal usage conditions.

Sagemcom do not accept any liability for the equipment if used outside the frame of its original designed purpose or any consequence that may arise from this usage.

Should any malfunction arise, the Sagemcom Helpdesk or your retailer will advise you how to proceed.

## **A) General Guarantee conditions**

Sagemcom undertakes to remedy by repair or exchange at its own convenience, free of charge for labour and replacement parts, any defects in the equipment during the guarantee period of 12 (twelve) months or 3 (three) months for accessories, from the date of original invoice of the Equipment, where those defects are a result of faulty workmanship.

Unless the customer has concluded with Sagemcom a maintenance contract in respect of the equipment which specifically provides for repairs to be carried out at the customer's premises, the repairs will not be carried out on the equipment at the customer premises.

The customer must however return the defective equipment at his/her own expense, to the address supplied by the Sagemcom Helpdesk or by the retailer.

In the case that a product needs to be sent in for a repair, it must always be accompanied by a proof of purchase (which is not altered, written on or in any way made illegible) showing that the product is still under guarantee. In the case that no proof of purchase is enclosed, the Sagemcom repair centre will use the production date as its reference for establishing the guarantee status of the product.

Apart from all legal obligatory rules, Sagemcom, do not give any Guarantee, either implicit or explicit which is not set force in the present section, and can not be held responsible for any direct or indirect, material or immaterial damage, either in or out of the frame of the present guarantee.

If any provision of this guarantee shall be held to be in whole or in part invalid or illegal due to an obligatory rule applicable to consumers pursuant to their national legislation, such invalidity or illegality shall not impair or affect the remaining provisions or parts of this guarantee.

This guarantee does not affect the Customer statutory rights.

## **B) General Guarantee conditions**

Sagemcom shall have no liability under the guarantee in respect of:

- Damage, defects, breakdown or malfunction due to one or more of the following:
  - Failure to properly follow the installation process and instructions for use
  - An external cause to the equipment (including but not limited to: lightning, fire, shock, vandalism, inappropriate conditions of electrical network or water damage of any nature)
  - Modifications made without the written approval of Sagemcom
  - Unsuitable operating conditions, particularly of temperature and humidity
  - Repair or maintenance of the equipment by persons not authorised by Sagemcom
- Wear and tear from normal daily use of the equipment and its accessories
- Damage due to insufficient or bad packaging of equipment when returned to Sagemcom
- Usage of new versions of software without the previous approval of Sagemcom
- Work on any equipment or software modified or added without the prior written consent of Sagemcom
- Malfunctions not resulting from the Equipment or from software installed in user workstations for the purpose of use of the equipment.

Communication problems related to an unsuitable environment including:

- Problems related to access and/or connection to the Internet such as interruptions by access networks or malfunction of the line used by the subscriber or his correspondent
- Transmission faults (for example poor geographical coverage by radio and TV transmitters, interference or poor line quality)
- Local network faults (wiring, servers, workstations) or the failure of the transmission network (such as but not limited to interferences, fault or poor quality of the network)
- Modification of the parameters of the cellular or broadcast network carried out after the sale of the Product
- Normal servicing (as defined in the user guide supplied with the equipment) as well as malfunctioning due to servicing not being carried out. Servicing costs are in any event always borne by the customer.

- Malfunctions resulting from the usage of products, consumables or accessories not compatible with the equipment.

### **C) Out of Guarantee Repairs**

In the cases set forth in B) as well as after expiry of the guarantee period, the customer must ask the Authorised Sagemcom Repair Centre for a cost estimation prior to work being carried out. In such cases, the repair and delivery costs will be invoiced to the customer.

The foregoing shall apply unless otherwise agreed in writing with the customer and only for the United Kingdom and Ireland.

**[www.sagemcomdigital.co.uk](http://www.sagemcomdigital.co.uk)**



# **SAGEMCOM**

## **Sagemcom Broadband SAS**

Headquarters: 250, route de l'Empereur  
92848 Rueil-Malmaison Cedex - France

Tel. +33(0)1 57 61 10 00 - Fax: +33(0)1 57 61 10 01

[www.sagemcom.com](http://www.sagemcom.com)

All rights reserved. The information and specifications included are subject to change without prior notice. Sagemcom Broadband SAS tries to ensure that all information in this document is correct, but does not accept liability for error or omission. Non contractual document. All trademarks are registered by their respective owners. Simplified joint stock company - Capital 35 703 000 € - 518 250 360 RCS NANTERRE.