


Hush Smart Baby Monitor

^{z Z}
Hush



www.hushviewer.com



Works with both Apple iOS and Android. Secure access over any Internet connected device from anywhere in the world

Hush Smart Baby Monitor



Initial Setup

- Open the box, and connect your Hush Baby Monitor² to your network router via the supplied Network Cable⁵.
- Screw the supplied Wireless Antenna Aerial³ into the back of the Hush Baby Monitor and angle upwards.
- Plug the 5V DC Power Supply Adaptor⁴ into the correct socket (labelled 5V) on the Hush Baby Monitor and turn the power on.
- Use the supplied QR codes to download the Hush App (iOS or Android) or visit www.hushviewer.com for more information.
- Once installed, open up the Hush App and search for monitors.

[It may take up to two minutes for the Hush Baby Monitor to appear in the App]

Setup WiFi

- Within the Hush App go to **Settings** → **Setup WiFi**
- Select your Hush Baby Monitor and choose from the list of available networks. You may then be prompted to enter your wireless password. If you do not have a password on your WiFi network simply select **OK**.
- A confirmation message that the Hush Baby Monitor has successfully connected to your WiFi network will then be visible.
- The Network Cable can be disconnected, and the Hush Baby Monitor can be moved to your room of choice.

[It may take up to two minutes for the Hush Baby Monitor to appear in the App]

Setup External Access

- External Access allows you to connect to your Hush Baby Monitor from outside your home network.
- Within the Hush App go to **Settings** → **Enable External Access**

Product Packaging List:

- | | |
|-----------------------------|---------------------------------|
| (1) Quick Start Guide | (4) 5V DC Power Supply Adaptor |
| (2) Hush Baby Monitor | (5) Network Cable (RJ45) |
| (3) Wireless Antenna Aerial | (6) Mounting bracket and screws |

- Select your Hush Baby Monitor and enter a unique username and password (of choice) for future access. You may also be asked for a serial code which can be found on the underneath side of the Hush Baby Monitor.
- A confirmation message that the Hush Baby Monitor has successfully been enabled for external access will then be visible.

[please take care to remember your username and password]

Using Remote Access

- When not connected to your home network you can use Remote Access to view your camera. Mobile Data Network charges may apply if using 3G/4G.
- Within the Hush App go to **Connect** and login using the previously created username and password.
- If you would like to connect without using an App, please visit www.hushviewer.com for more information.

Rename Monitor

- Within the Hush App go to **Settings** → **Rename Monitor**
- Select your Hush Baby Monitor and enter a new name of your choice.
- A confirmation message that the Hush Baby Monitor name has been changed will then be visible.

Troubleshooting

- If for any reason you have problems connecting, there is a reset button on the bottom of the camera² to bring it back to the original manufacturers settings. Use this quick guide¹ to start the setup from fresh.
- For issues or further information regarding your Hush Baby Monitor please visit www.hushviewer.com.



Technical Specification

Colour:	White
Image:	Video (MJPEG)
Lens:	F:3.6/F:2.4 IR Lens
Pixels:	300K (640x480)
Camera Movement:	Left/Right (270°) Up/Down (120°)
Network (Wired):	1x RJ45 10/100Mbps
Network (Wireless):	WEP/WPA/WPA2 (TKIP & AES)
Connectivity:	Universal
Remote Access:	Yes
Audio:	Two-Way
Night IR:	15m (IR LEDs)
Power:	Mains 5V DC (2.5A) 5W (Consumption)