



Berkshire 200

Thank you for choosing a Berkshire 200 telephone. You have selected a carefully designed telephone that incorporates the very latest technology, offering a stylish instrument and providing many years of excellent service.

This booklet will ensure you obtain the best use of your telephone.



Preparing to use your Berkshire 200

INITIAL CHECK

Our telephones are checked, tested and leave us in perfect condition. If yours is damaged, please return it to your supplier with proof of purchase, for a replacement.

TELEPHONE NUMBER LABEL

The telephone incorporates a label underneath the handset for recording frequently used telephone numbers. To remove the plastic cover, operate the release clip with your thumb nail and hinge upward.

CONNECTION

The Berkshire 200 telephone can be connected either to a Direct Exchange Line, or as an extension to a compatible company exchange (PABX).

HANDSET CORD

This cord will require connection between the telephone and handset. Take any end of the handset cord, locate the port marked 'HANDSET' on the left hand side of the Berkshire 200 and simply push to locate. Connect the other end to the base of the handset to complete.

LINECORDS

The Berkshire 200 arrives with two line cords for customer selection. Select your required linecord (standard BS6312 BT-socket, or RJ45 socket for category 5 installations). The rear of the telephone has a port marked 'LINE', plug your selected linecord into this port first and the other end to your telephone line termination point. An RJ11 line cord is available as an option, ask your supplier for details.

WALL AND DESK MOUNTING KITS

A wall or desk mounting kit is available as an option, please contact your supplier for further information.

Using your Berkshire 200 with the Handset

RECEIVING CALLS

Incoming calls will be announced by the audible ringer and flashing LED. To answer the call, simply lift the handset.

ADJUSTING YOUR RINGER VOLUME

The ringer volume is controlled by a 3 position switch located at the rear of the telephone and indicated by the word 'RINGER'. Moving through the settings from left to right they are 'HIGH', 'MED' and 'LOW'.

ADJUSTING YOUR RINGER PITCH

The ringer pitch control is also a 3 position switch located at the rear of the telephone and indicated by the words 'RINGER PITCH'. Settings from left to right are 'HIGH', 'MED' and 'LOW'.

MAKING A CALL VIA THE HANDSET

- Pick up the handset and listen for dial tone
- Dial the required telephone number

(Note: making external calls from a company exchange (PABX) requires the number to be prefixed by an access digit, normally '9')

Using your Berkshire 200 with Headset

CONNECTING THE HEADSET

To connect the headset, insert the plug on the headset cord into the socket marked 'HEADSET' on the left hand side of the telephone.

NOTE: Headsets used with this telephone must comply with the standard EN6095.

RECEIVING CALLS

When your telephone rings, the default path for the call is to the handset. To receive it on the headset, press 'HEADSET' button once and the call is switched to the headset. This action will be confirmed by LED indication within the headset button. At the end of the call, press the 'HEADSET' button a second time to turn the headset off.

MAKING CALLS

Press the 'HEADSET' button to turn the headset on and dial as normal. When you have finished the call, press 'HEADSET' to turn the headset off.

Whether making or receiving calls the LED will flash if the 'HEADSET' button is pressed and no headset is connected.

ADJUSTING THE VOLUME

You can adjust the volume to the headset, by moving the sliding switch on the right hand side of the telephone.

TRANSFERRING CALLS

- FROM HANDSET TO HEADSET

If you have taken a call on the handset and wish to transfer it to your headset, press 'HEADSET'

and replace the handset.

- **FROM HEADSET TO HANDSET**

If you wish to transfer a call from your headset to the handset, simply pick up the handset. This action will switch off the headset.

Features and Facilities

TRANSFER KEY (RECALL)

Berkshire 200 telephones are provided with a 'TRANSFER' key, required by modern public and private exchanges, in order to gain access to various features such as 'transferring a call'. For this, the 2 position selector switch at the rear of the telephone, must be set to the 'T' (Time Break Recall) or 'E' (Earth Leg Recall) position, to suit your system requirements.

REDIAL KEY

If you wish to redial the last number you dialled, you can do so by lifting the handset and pressing the 'REDIAL' button.

MUTE KEY

The microphone in the handset / headset can be turned off (mute) in order for you to refer to a colleague without your caller hearing you.

- Pressing the 'MUTE' button turns off the microphone and gives visual LED indication within the 'MUTE' button.
- Pressing the 'MUTE' button again turns the microphone back on and the LED is turned off.

SWITCHABLE MESSAGE WAITING

There are three versions of Message Waiting Indication supported within the Berkshire 200 telephone (MW3, 8 and 10). This selection is made via a 4 position switch located to the rear of the phone, indicated by the letters 'MW'.

A 'RING INDICATOR' setting is provided that has additional benefit of being activated by short ring burst MW signals - see website for details.

In all cases, an LED in the top right hand corner of the telephone is used to indicate the selected functions and incoming calls.

Any questions you may have should be directed in the first instance to your telephone supplier with details of your PABX.

Further concerns may also be addressed by calling our Technical Support Department on 0845 421 0730 or visiting our website, www.attlecom.com/support.

MODEM PORTS

Your Berkshire 200 comes with two modem ports (BS6312 and RJ11) typically used for a PC modem, or as points of connection for additional telephones.

HEARING AID COMPATIBILITY

For hearing aid users, an inductive coupler has been installed in the handset of the Berkshire 200, to improve audible efficiency.

Installation Notes

MESSAGE WAITING

MW3 is used by systems that use high voltage DC signalling. MW8/10 however use line reversal methods to indicate that a message is present. Please check with your TelecomTeam/Provider for correct settings as it will depend on what switchboard you are connected to.

Help

If the telephone appears to be faulty when first connected, a few simple checks may help to identify some possible problems, as listed below:

NO DIAL TONE

- The handset is plugged into the handset socket not headset socket.
- Check that the telephone plug is fully inserted in the socket.
- If it is, try connecting the telephone into another socket, if available. If dial tone is now heard, the original socket is faulty.
- Alternatively, try connecting another telephone into your socket. If this telephone gives dial tone, then your new telephone is probably faulty.

ALL OPERATIONS SEEM SATISFACTORY

EXCEPT THE TRANSFER BUTTON

- Change the recall selector switch setting (T/E). If the transfer operation is now satisfactory, the problem is resolved.

For help with voicemail, call divert and call pickup please contact your Telecom Team/Provider as this will vary depending upon what switchboard you are connected to.

Compliance Notes

The Berkshire 200 may be connected to the following types of installation:

1. Direct Exchange Lines (DEL)
2. Compatible Private Automatic Branch Exchanges (PABX). Please contact the supplier of your Berkshire 200 to confirm compatibility with your PABX.

Whilst the Berkshire 200 is compliant as an extension to a compatible PABX system, it cannot be guaranteed to operate under all possible conditions of connection. Any case of difficulty should be referred in the first instance to the supplier of your telephone.

Guarantee

Your Berkshire 200 telephone is designed and manufactured to exacting quality standards. This enables ATL Telecom Limited to offer a 10 year guarantee from the date of purchase. This guarantee protects against faulty material or workmanship, applies to the UK only and is not transferable.

The terms and conditions under which the guarantee will be valid are as set out below.

1. Misuse or any modification carried out to the telephone, or operation other than in accordance with the instructions supplied, will invalidate the guarantee.
2. Damage arising from incorrect installation, accidental damage or consequential loss, are not covered under the guarantee.
3. In the event of a fault developing during the period of the guarantee, the complete telephone should be returned to your supplier, adequately and safely packed, together with proof of date of purchase.
4. The liability of ATL Telecom Limited will be limited to the cost of repair or complete replacement of the same defective instrument, at the discretion of the company. In the event that the same item is not available, a suitable alternate will be offered.
5. The terms of this guarantee do not affect your statutory rights.

Manufacturer's Declaration

ATL Telecom Limited declares that this product is in conformity with the essential requirements of the 'R&TTE directive 1999/5/EC'

Note: A copy of the Declaration of Conformity is available upon request from ATL Telecom Limited.

ATL Telecom Limited,
Lakeside, Fountain Lane,
St Mellons,
Cardiff
CF3 0FB

Telephone: 0330 333 8250
Facsimile: 0330 333 8251

www.atltelecom.com

1/340/003/610 Issue 02



January 2010